# !

## WARNING

Causes serious eve irritation.

Wash thoroughly after handling. Wear eye protection, protective gloves, protective clothing.

**IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

**If eye irritation persists:** Get medical advice/attention.

NFPA® RATINGS: Health: 1; Flammability: 0; Reactivity: 0

## **CONTAINS/CAS NUMBER:**

Water/7732-18-5; Tetrasodium Etidronate/3794-83-0; Polymers/Trade Secret; Sodium Sulfite/7757-83-7; Sodium Dodecyl Diphenyl Ether Disulfonate/119345-04-9; Phosphoric Acid/7664-38-2





# **RUST AWAY**

Easy Soak Formula Removes Rust From Metal Without Scrubbing

> INHIBITS FLASH RUSTING FOR WEEKS AFTER TREATMENT

> > • NEUTRAL pH • NO VOC's

BIODEGRADABLE
NON-TOXIC

NON-CORROSIVE

## **KEEP OUT OF REACH OF CHILDREN**

NET CONTENTS: One Gallon (128 fl. oz.)

Manufactured By: Total Solutions<sup>®</sup> • 1-800-743-6417 PO Box 240014 • Milwaukee, WI 53224 • athea.com

### DESCRIPTION

Rust Away is the safe and effective way to remove rust from metal without scrubbing. Will not harm surfaces including rubber, plastic, vinyl, PVC, aluminum, copper, and brass. The pH neutral formula is non-toxic, biodegradable, and non-flammable.

Simply clean rusty items to remove dirt and oils before submerging object in the liquid. Rust severity will determine soak time which can range from hours to overnight for stubborn deposits.

Objects treated with Rust Away can be towel dried or air dried and will resist flash rusting for weeks.

## DIRECTIONS

**SURFACE PREPARATION:** Remove loose rust deposits and clean surface thoroughly to remove dirt, oil, and grease.

Fully submerge parts to be cleaned in Rust Away and check periodically. Time to remove rust can vary depending on severity of deposits and can range from hours to overnight.

Once rust is removed, rinse object in water and towel dry or air dry.

Rust Away can be re-used until the solution is no longer active at removing rust.

#### DISPOSAL

Offer empty container for recycling. If recycling is not available, discard container in trash.



For industrial and commercial use only. For additional information, see Safety Data Sheet.